



## [HP HP0-064](#)

**Exam Name:** HP BladeSystems C-Class Solutions 1

**Q & A :** 66 Q&As

***Pdf Demo***

### **Quality and Value for the HP0-064 Exam**

[Just4Exams Practice Exams](#) for HP Certification I HP0-064 are written to the highest standards of technical accuracy, using only certified subject matter experts and published authors for development.

### **100% Guarantee to Pass Your HP0-064 Exam**

If you do not pass the Certification I HP0-064 exam on your first attempt using our Just4Exams **HP0-064 testing engine and pdf study guide**, we will give you a FULL REFUND of your purchasing fee.

### **Downloadable, Interactive HP0-064 Testing engines and PDF Version**

Our Exam Preparation Material provides you everything you will need to take a [Certification I certification](#) examination. Details are researched and produced by [HP Certification](#) Experts who are constantly using industry experience to produce precise, and logical.

#### **Free HP0-064 Exams:**

***This is demo only, this pdf do not include the questions and answers picture***

Exam : HP HP0-064

Title : HP BladeSystems C-Class Solutions 1

1. Which port on a BladeSystem c-Class enclosure serves as a service port for temporary connection to a PC?

- A. USB port
- B. serial connector
- C. enclosure link-up port
- D. enclosure link-down port

Answer: C

2. You are install an HP Gbe2c Ethernet Blade Switch in a BladeSystem c-Class enclosure. Which steps should you take before beginning the installation?

- A. Power down the enclosure
- B. Connect the switch to the LAN for configuration
- C. Manually enable the switch interconnect ports 17 and 18
- D. Record the media access control (MAC) address of the switch
- E. Make sure that the server NIC configuration matches the interconnect bay selected

Answer: D E

3. Click the Task Button

Match the number to the correct part of the HP BladeSystem c-Class enclosure.

Answer:

4. Which switch should you use as the primary Fabric Configuration Server in a mixed fabric containing multiple Brocade switches?

- A. the primary switch each zone
- B. the switch with the most available ports
- C. it does not matter which switch you use
- D. any switch with the current Fabric OS installed

Answer: D

5. You want to establish a connection to the switch through the Onboard Administrator. Your workstation has a terminal application installed and a null modem serial cable connected to the Onboard Administrator module, but you are unable to connect. What is the most probable cause of the error?

- A. You have the wrong IP address
- B. Another user is logged in to the switch
- C. You can access the switch only through Advanced Web Tools
- D. You can access the switch only through the Application program interface (API)

Answer: B

6. You are configuring the Ethernet interconnects for a customers system. The customer is deploying a solution that maintains a 1:1 ratio between servers and switch ports. Which solution will be most cost-effective for this customer?

- A. Virtual Connect
- B. Redundant GbE2c switches
- C. HP Ethernet Pass-Thru Module
- D. HP InfiniBand 4X DDR Switch Module

Answer: C

7. In a BladeSystem c-Class enclosure, how are the interconnects connected to the device bays?

- A. CAT5 cables
- B. RJ-45 cables
- C. 100-pin connectors
- D. connections are hard-wired

Answer: D

8. When you are using the BladeSystem power calculators, how should you estimate the power provisioning?

- A. at 80% load
- B. at 90% load
- C. at 60% load
- D. at 100% load

Answer: D

9. Of the requirements to configure a Brocade 4Gb SAN switch, which component is optional?

- A. IP address
- B. Ethernet cable
- C. access to an FTP server
- D. Small form factor pluggable (SFP) transceivers

Answer: C

10. To complete the installation and ensure proper cooling, which step should you take after you have installed the server blades in a BladeSystem c-Class enclosure?

- A. Install blade and fan blanks
- B. Install redundant cooling fans
- C. Use Thermal Logic software to restrict BTUs

D. Activate the Insight Display and check for error messages.

Answer: A

11. You have just installed an interconnect switch in an HP BladeSystem c-Class, and the switch does not power up. What should you check first?

- A. interconnect type and location
- B. mezzanine cards are correctly installed
- C. server blade is in the correct device bay
- D. enclosure and switch status in the Onboard Administrator GUI

Answer: D

12. If you are installing a Type 1 mezzanine card in a BladeSystem c-Class enclosure, which step should you take after you have identified the target server blade in the enclosure?

- A. Back up all server data
- B. Remove the server blade
- C. Remove the access panel
- D. Power down the server blade

Answer: A

13. If you are installing a GbE2c switch, how can the switch obtain an IP address remotely?

- A. through a Telnet connection on any server with access to the internet
- B. from a BOOTP server on the network, using the switch's MAC address
- C. through a VT100 terminal emulation session on any server on the network
- D. through the switch browser-based interface (BBI) or command line interface (CLI)

Answer: B

14. Which statements describe the default role of the operator access level in an HP GbE2c switch for BladeSystem c-Class?(Select two).

- A. An operator can reset ports or the entire switch
- B. An operator can change user and administrator passwords
- C. Operator-level access is the default on HP GbE2c switches
- D. An operator can make permanent changes to the switch configuration
- E. Any configuration changes an operator makes are undone by resetting the switch

Answer: A E

15. A customer wants to install a BladeSystem c-Class enclosure in a third-party rack, but the rack doors interface with the enclosure. Which actions will allow the customer to keep the rack?(Select two)

- A. Remove the door
- B. Adjust the enclosure depth
- C. Use an HP rack adapter kit
- D. Adjust the columns if possible
- E. Populate only the half-height bays

Answer: A D

More [HP0-064 Braindumps](#) Information

#### Related HP0-064 Exams

HP0-M15	HP0-S18	HP0-M16	HP0-A01	HP0-M18
HP0-M19	HP0-S19	HP0-Y20	HP0-Y19	HP0-J24
HP0-J15	HP0-X02	HP0-063	HP0-J22	HP0-S17
HP0-Y21	HP0-Y11	HP0-M22	HP0-P10	HP0-P17

#### Other HP Exams

HP0-632	HP0-198	HP0-S11	HP0-661	HP2-E19
HP0-D02	HP0-874	HP0-084	HP0-072	HP0-446
HP0-920	HP0-264	HP0-678	HP0-648	HP0-662
HP0-053	HP0-A24	HP0-698	HP0-243	HP0-J20