



[HP HP0-086](#)

Exam Name: HP Bladesystem p-Class Solutions 1

Q & A : 120 Q&As

[Pdf Demo](#)

Quality and Value for the HP0-086 Exam

[Just4Exams Practice Exams](#) for HP Certification III HP0-086 are written to the highest standards of technical accuracy, using only certified subject matter experts and published authors for development.

100% Guarantee to Pass Your HP0-086 Exam

If you do not pass the Certification III HP0-086 exam on your first attempt using our Just4Exams ***HP0-086 testing engine and pdf study guide***, we will give you a FULL REFUND of your purchasing fee.

Downloadable, Interactive HP0-086 Testing engines and PDF Version

Our Exam Preparation Material provides you everything you will need to take a [Certification III certification](#) examination. Details are researched and produced by [HP Certification](#) Experts who are constantly using industry experience to produce precise, and logical.

Free HP0-086 Exams:

This is demo only, this pdf do not include the questions and answers picture

Exam : HP HP0-086

Title : HP BladeSystem p-Class Solutions I

1. You are configuring an enhanced server blade enclosure that is fully populated with BL35p server blades to boot Windows Server 2003 from a single MSA1000 storage solution. What is the minimum number of logical units (LUNs) you must create on the MSA1000?

- A. 2
- B. 4
- C. 8
- D. 16

Answer: D

2. You have an enhanced server blade enclosure fully populated with ProLiant BL35p server blades. You connect to the bottom server

blade in server bay 1 using the local I/O cable, and want to enable the Static IP Bay Configuration feature to automatically assign IP addresses to all server blade iLOs in the enclosure. However, the Static IP Bay Configuration option is not available. Why?

- A. A DHCP server exists on your network.
- B. You are not connected to the first server blade in the first bay.
- C. The management module on the back of the server blade enclosure is incorrectly configured.
- D. The power enclosure and the server blade enclosure management ports are not cabled or cabled incorrectly.

Answer: B

3. What is the recommended environment for using high-voltage PDUs?

- A. when using single-phase power and 3U power enclosures
- B. when using facility DC power with a fully-populated 42U rack
- C. when using 3U power enclosures with the non-enhanced server blade enclosures
- D. when using a large number of server blades that place a high load on the power bus
- E. when using the enhanced server blade enclosure in a redundant power configuration

Answer: D

4. What is the maximum combination of power and enhanced server blade enclosures that can be connected to a mini bus bar?

- A. 1 power and 2 server blade enclosures
- B. 1 power and 3 server blade enclosures
- C. 2 power and 2 server blade enclosures
- D. 2 power and 3 server blade enclosures

Answer: D

5. What is the default user name and password for the GbE2 Interconnect Switch administrator account?

- A. user name: <blank>, password: hp
- B. user name: admin, password: admin
- C. user name: admin, password: compaq
- D. user name: Administrator, password: password

Answer: B

6. What is the recommended environment for using high-voltage modular power distribution units (PDUs)?

- A. when using 1U power enclosures
- B. when using 3U, single-phase power enclosures
- C. when using 3U, three-phase power enclosures and redundant power
- D. when using 3U, three-phase power enclosures and non-enhanced server blade enclosures

Answer: A

7. You have a fully populated enhanced server blade enclosure. You connect your laptop with a crossover cable to the RJ-45 port of the local I/O cable and insert the other end of the local I/O cable into the local I/O port in the front of blade 3. You then set your laptop to the IP address 192.168.1.2 and the subnet mask 255.255.255.0. When you enter http://192.168.1.1 in the Microsoft Internet Explorer address field, you receive the "Page not found" error message. Why?

- A. The default IP address of the iLO is 192.168.0.1.
- B. The iLO Advanced firmware is older than version 1.64 and must be upgraded first.
- C. The local I/O cable is already a crossover cable, thus another crossover cable is not required.
- D. The power enclosure and the server blade enclosure management ports are not cabled or cabled incorrectly.

Answer: C

8. Which configuration requires two power zones to be enabled on the power enclosure management modules?

- A. any configuration that mixes a single phase and three-phase power
- B. full 42U rack with four 3U power enclosures connected by mini bus bars
- C. full 42U rack with four 3U power enclosures connected by scalable bus bars
- D. any configuration that has two or more 3U power enclosures connected to the facility DC power

Answer: B

9. You connect to the iLO of a ProLiant BL20p G2 server blade through the Ethernet port. The iLO web interface does not display the BL p-Class tab. Why?

- A. The BL p-Class tab is disabled by default.
- B. The iLO firmware is older than version 1.64.
- C. The iLO Advanced is not licensed in the HP BladeSystem Integrated Management.
- D. The BL p-Class tab is only available when accessing the iLO through the local I/O port.

Answer: B

10. You are creating a VLAN on a GbE2 Interconnect Switch. This VLAN must include the crosslink ports. Which ports must you include?

- A. ports 1 and 2
- B. ports 3 and 4
- C. ports 15 and 16
- D. ports 17 and 18

Answer: D

11. Which HP SIM plug-in component enables scanning for and patching of network vulnerabilities?

- A. PIM
- B. PMP
- C. VMM
- D. VPM

Answer: D

12. Which UPS supports the p-Class infrastructure and is 3U high?

- A. HP R1500XR
- B. HP R3000XR
- C. HP R5500XR
- D. HP R12000XR

Answer: C

13. You have an enhanced server blade enclosure connected to a single 3U power enclosure. Only side A of the server blade enclosure is connected to the power enclosure. Which server blade enclosure bays receive DC power?

- A. bays 1 through 8
- B. bays 1 through 8, plus the interconnect bays
- C. bays 1 through 4, plus the interconnect bays
- D. bays 1 through 4, plus the interconnect bay on side A
- E. bays 5 through 8, plus the interconnect bay on side A

Answer: C

14. When must the load-balancing cable be installed?

- A. when one or more power enclosure pairs are installed in a rack
- B. when an odd number of power enclosures are installed in a rack
- C. when a three-phase power enclosure is connected to the original server blade enclosure
- D. when one power enclosure provides redundant power to the original server blade enclosure

Answer: A

15. How many server-facing Fibre Channel ports are included in the Brocade 4Gb SAN switch for the HP BladeSystem?

- A. 4
- B. 8
- C. 12
- D. 16

Answer: B

16. What is the default administrator account username and password for the Brocade 4Gb SAN Switch?

- A. admin/admin
- B. admin/password
- C. administrator/<blank>
- D. administrator/password

Answer: B

17. When accessing the iLO BL p-Class tab, you receive the "Unable to collect rack data" error message. Why? (Select two.)

- A. At least one server blade iLO is not configured.
- B. You have not yet licensed all server blade iLOs.
- C. At least one management module has mismatched firmware.
- D. A DHCP server exists on the network and conflicts with the Static IP Bay Configuration feature.
- E. At least one power enclosure or server blade enclosure does not meet the minimum firmware requirements.

Answer: CE

18. How do the HP ProLiant BL p-Class server blades support network attached storage (NAS)? (Select two.)

- A. through the embedded network adapters
- B. through optional multifunction network adapters
- C. through optional mezzanine or balcony host bus adapters
- D. through the additional NIC ports on the front of the interconnect switches
- E. through the additional NIC ports on the back of the interconnect switches

Answer: AB

19. Which power distribution option requires the dual power input kit for power redundancy?

- A. mini bus bar
- B. power bus box
- C. scalable bus bar
- D. facility DC power

Answer: A

20. Which HP server blade uses a Fibre Channel loop to combine two internal SAN port connections to a single external physical connection?

- A. ProLiant BL35p
- B. ProLiant BL45p
- C. ProLiant BL20p G2
- D. ProLiant BL20p G3

Answer: A

More [HP0-086 Braindumps](#) Information

Related HP0-086 Exams

HP0-S16	HP0-D04	HP0-J26	HP0-P13	HP0-M23
HP0-918	HP0-M28	HP0-S14	HP0-920	HP0-265
HP0-263	HP0-084	HP0-239	HP0-085	HP0-266
HP0-205	HP0-071	HP0-286	HP0-080	HP0-787

Other HP Exams

HP2-T14	HP0-661	HP2-033	HP0-664	HP0-M22
HP0-M19	HP0-742	HP0-A08	HP0-760	HP0-302
HP0-091	HP0-Y15	HP0-198	HP0-A01	HP0-S23
HP0-336	HP2-Q01	HP0-265	HP0-S13	HP0-M15