



## **HP HP0-066**

**Exam Name: Advanced Lights Out**

**Q & A : 75 Q&As**

**Pdf Demo**

### **Quality and Value for the HP0-066 Exam**

[Just4Exams Practice Exams](#) for HP Certification I HP0-066 are written to the highest standards of technical accuracy, using only certified subject matter experts and published authors for development.

### **100% Guarantee to Pass Your HP0-066 Exam**

If you do not pass the Certification I HP0-066 exam on your first attempt using our Just4Exams **HP0-066 testing engine and pdf study guide**, we will give you a FULL REFUND of your purchasing fee.

### **Downloadable, Interactive HP0-066 Testing engines and PDF Version**

Our Exam Preparation Material provides you everything you will need to take a [Certification I certification](#) examination. Details are researched and produced by [HP Certification](#) Experts who are constantly using industry experience to produce precise, and logical.

#### **Free HP0-066 Exams:**

***This is demo only, this pdf do not include the questions and answers picture***

Exam : HP HP0-066

Title : Advanced Lights-Out

1. What happens when iLO loses its connection to the directory server?
  - A. It immediately sends an alert to the HP SIM server.
  - B. It terminates the connection and returns you to the Login screen.
  - C. It disables the Enable Directory Authentication option and forces you to use the local accounts.
  - D. It displays the Directory Server unavailable message and tries to reconnect at 90-second intervals.

Answer: B

2. You are using a Linux client machine and the Firefox web browser to connect to the iLO. When sizing the Remote Console window, it turns grey. Why?

- A. The client machine does not have JVM 1.4.2 or greater installed.
- B. The iLO does not support Firefox-based Remote Console access.
- C. The iLO does not have the Terminal Pass-Through option enabled.
- D. The Remote Console has the High Performance Mouse option enabled.

Answer: A

3. The Remote Console Port Configuration option in iLO is set to Automatic. You have no trouble connecting to the iLO using the Remote Console, but your Telnet connection fails. Why?

- A. Telnet requires the Remote Console Data Encryption to be enabled.
- B. Telnet requires Java Virtual Machine (JVM) to be present on the client.
- C. Telnet cannot automatically enable port 23, which is the default Remote Console port.
- D. Telnet by default attempts to access port 22, whereas the Remote Console port defaults to 23.

Answer: C

4. What does the sequential flashing pattern of the iLO 2 LEDs 1-8 indicate?

- A. iLO 2 runtime failure
- B. iLO 2 hardware failure
- C. iLO 2 normal operation
- D. iLO 2 in flash recovery mode

Answer: D

5. After removal of the iLO Diagnostic Port cable on a server blade, you immediately attempt to connect to the same iLO through the iLO management port in the rear of the server blade enclosure. The connection fails. Why?

- A. You must reset the iLO to enable the rear iLO management port.
- B. You must re-enable the rear iLO management port before disconnecting from the iLO Diagnostic Port.
- C. You must allow at least one minute for the network switchover between the iLO Diagnostic Port and the rear iLO management port.
- D. You must log out and terminate your browser session before disconnecting from the iLO Diagnostic Port.

Answer: C

6. Which alert will the iLO 2 generate when it detects that a server blade was manually forced by the customer to power on despite the BL p-Class infrastructure reporting insufficient power?

- A. Rack Server Power On Failed
- B. Rack Server Power On Forced
- C. Rack Server Power Oversubscribed
- D. Rack Server Power On Manual Override

Answer: D

7. When connected to a Linux server with the iLO Remote Console, some of the POST messages requiring your response do not display during the boot process. How can you remedy this situation?

- A. Disable the Terminal Services Pass-Through option.
- B. Edit the startup script to allow more time for keyboard input.
- C. Disable the iLO Remote Console High Performance Mouse option.
- D. Configure the iLO to refresh the Remote Console text window at a higher rate using the Remote Console Text Refresh option.

Answer: B

8. Which Integrated Lights-Out (iLO) LAN connection scenario gives the best resource utilization?

- A. 1Gb network
- B. corporate network
- C. iLO shared network
- D. dedicated management network

Answer: C

9. How many concurrent non-Remote Console user connections does iLO allow?

- A. 1
- B. 2
- C. 10
- D. 12

Answer: C

10. When does iLO request its IP address from the DHCP server, provided this option is enabled?

- A. after the server completes its POST

- B. after power is first applied to the iLO
- C. after the operating system successfully boots
- D. after the iLO ROM-Based Setup Utility prompt displayed during server POST disappears

Answer: B

11. When activating the iLO Virtual Media applet, the Virtual Media window displays a red X or a gray blank screen. Why?

- A. The iLO Advanced Pack license is not activated.
- B. The Virtual Media feature is disabled in the iLO Global Settings tab.
- C. The iLO did not detect any supported floppy or CD-ROM drives in the server.
- D. An incorrect version of or no Java Virtual Machine (JVM) is installed on the client.

Answer: D

12. Which CLI commands display the DHCP-obtained IP address of the Lights-Out 100i management processor on an HP ProLiant DL145 G1 server?

- A. net - stat
- B. cfg - ipcfg
- C. cfg - show
- D. net - showcfg

Answer: A

13. You have requested, obtained, and imported into iLO a certificate from a trusted Certificate Authority (CA). However, your login into iLO using the two-factor Smart Card authentication fails. Why?

- A. The Directory Services server cannot be contacted.
- B. The certificate is not mapped to a local user account.
- C. The Enable Directory Authentication option is turned off.
- D. The certificate was invalidated when the iLO was reset.

Answer: B

14. Which alert will the iLO 2 generate when it detects that a server blade was unable to power on because the BL p-Class infrastructure indicated that insufficient power was available to power on the server blade?

- A. Rack Server Power On Failed
- B. Rack Server Power On Halted
- C. Rack Server Power On Delayed
- D. Rack Server Power Oversubscribed

Answer: A

15. What happens when the iLO requests an IP address from a DHCP server but does not receive it?

- A. It remains disabled.
- B. It uses its default static IP address.
- C. It reissues the request at 90-second intervals.
- D. It issues three more requests at 30-second intervals before disabling itself.

Answer: C

More [HP0-066 Braindumps](#) Information

#### Related HP0-066 Exams

HP0-M15	HP0-S18	HP0-M16	HP0-A01	HP0-M18
HP0-M19	HP0-S19	HP0-Y20	HP0-Y19	HP0-J24
HP0-J15	HP0-X02	HP0-063	HP0-J22	HP0-S17
HP0-Y21	HP0-Y11	HP0-M22	HP0-P10	HP0-P17

#### Other HP Exams

HP0-D01	HP0-197	HP0-238	HP0-756	HP0-M20
HP0-239	HP0-761	HP0-P11	HP0-310	HP0-068
HP0-A02	HP0-762	HP0-A24	HP0-M28	HP0-096
HP0-S17	HP2-K08	HP0-276	HP0-685	HP0-094